

SELMER PARIS WOODWIND MOUTHPIECES

S-90 SAXOPHONE MOUTHPIECES

ITEM #	DESCRIPTION	LIST PRICE				
S411	SOPRANO SAXOPHONE					
S412	ALTO SAXOPHONE					
S414	TENOR SAXOPHONE					
S415	BARITONE SAXOPHONE					
MODEL PREFIX	INSTRUMENT TYPE		170	180	190	200
S411	SOPRANO SAXOPHONE	MODEL NUMBER	S411170	S411180	S411190	S411200
		TIP OPENING	1.2	1.4	\$1.80	2
		FACING LENGTH	24	22	24	27
S412	ALTO SAXOPHONE	MODEL NUMBER	S412170	S412180	S412190	S412200
		TIP OPENING	1.25	1.5	1.9	2.05
		FACING LENGTH	24	22	24	27
S414	TENOR SAXOPHONE	MODEL NUMBER	S414170	S414180	S414190	S414200
		TIP OPENING	1.3	1.7	2	2.1
		FACING LENGTH	24	22	24	27
S415	BARITONE SAXOPHONE	MODEL NUMBER	S415170	S415180	S415190	S415200
		TIP OPENING	1.35	1.8	\$2.10	2.2
		FACING LENGTH	24	22	24	27

